

PERISTALTIC PUMP SELECTION

February 20, 2025

Ana Dias and Matt Jackson

TRAINING – WEBINAR SESSION 3



Peristaltic Pump Overview



Peristaltic Pump Applications



Peristaltic Pump Selection

QUICK RECAP – WEBINARS 1 & 2

Webinar 1

- What is a metering pump
- How a peristaltic pump works
- Common applications
- Benefits
- Key Components
- ProMinent Offering

Webinar 2

- When a peristaltic pump should be used
- When a peristaltic pump should not be used
- Advantages
- Common applications in specific industries

PROMINENT DULCOFLEX COMPLETE PRODUCT LINE

DULCOFLEX DFXa

Capacities up to:
17.7 GPH (65 LPH)



DULCOFLEX DFBu

Capacities up to:
337 GPH (1,532 LPH)



DULCOFLEX DFCu

Capacities up to:
106.4USGPM (24,163 LPH)



DULCOFLEX DFYa

Capacities up to:
174.4 GPH (660 LPH)



DULCOFLEX DFBr

Capacities up to:
337 GPH (1,532 LPH)



DULCOFLEX DFDu

Capacities up to:
160USGPM (36,336 LPH)



Pressures up to
218PSI/15Bar(g)

AGENDA

- Selecting the Right Pump
- Selection & Quotation Tools
- Designing a System
- Installation Tips



Selecting the Right Pump




INFORMATION TO GATHER




Chemical/Fluid




Flow Rates



Pressures



Temperatures



Process Requirements



System Design and Layout



Communication Needs



Approvals or Certifications

CHEMICAL

➤ Chemical Name and Concentration

- To determine material for the tube/hose and pump connections
- Depending on the concentration, the same chemical may require different material
- If incorrect material is selected, tube/hose lifetime is reduced due to swelling and/or delamination



HOSE MATERIAL



CHEMICAL

➤ Chemical Viscosity

- Viscosity will have an impact on discharge pressure as well as the pump type that can be used. The DFXa peristaltic tube pump can pump viscosities up to 900,000 cPs
- For the hose pumps, the larger the pump, the more viscous the product that it can pump. Hose pumps can pump up to 20,000 cPs
- Viscosity will also affect the amount of suction lift the pump can perform in a lift application



CHEMICAL

➤ Chemical Density

- Density will affect the amount of suction lift that the pump can perform
- Slurries with a high specific gravity can affect the inlet pressure at the suction port of the pump if the pump is situated in a flooded suction condition
- The maximum allowable inlet pressure at the suction port of the pump is 3Bar(g)/43PSIG



FLUID

➤ Particle Size

- In order for the solids to get through the pump without dewatering, the pump needs to be sized properly. Otherwise, the solids collect, dewater, and cannot get through the pump
- In a shear sensitive application such as pumping fruit, or candy the maximum solid size needs to be known to make sure that the product going through the pump is not damaged
- Maximum particle size:
 - For soft solids: <25% of the hose ID
 - For hard solids: <15% of the hose ID



FLUID

➤ Solid Content

- Hose pumps can pump slurries containing up to 80% solids by weight, if the solid content is higher than this, the pump will have difficulty pumping the solution, as at this point, it is basically pumping a solid



FLOW

➤ Flow Rate

- This information is crucial to size any pump
- Recommended speed for better hose lifetime:
 - around 20-40 rpm (for continuous duty)
 - 20-30 rpm for polymer, slurry and other viscous fluid ($> 1,000$ cPs)
- The higher the speed, the shorter the hose lifetime



PRESSURE

➤ Discharge Pressure

- This is crucial information to select the pump technology (roller or shoe)
 - Shoe pump: max. 15 Bar(g) (218 PSIG)
 - Roller pump: max. 8 Bar(g) (116 PSIG)
- Fabric reinforced hose can handle higher pressures than tube
- The higher the pressure, the shorter the hose lifetime



TEMPERATURE

➤ Chemical temperature

- Max. 50-60°C (122-140°F) for continuous duty, and up to 80°C (176 °F) for short period of time
- The higher the temperature, the shorter hose lifetime



➤ Ambient temperature

- -10 to 45°C (14 to 113°F)
- If pump is installed outdoors, shelter is recommended to protect pump from rain and sun

PROCESS REQUIREMENTS

➤ Intermittent or Continuous Operation

- For intermittent duty: a smaller pump and operating it faster
- For continuous duty: a larger pump and running it slower

A balance of pump cost vs. hose lifetime



SYSTEM DESIGN AND LAYOUT

➤ Flooded Suction or Suction Lift

- Pump can lift up to 8m (26 ft)
- Suction piping to be as short as possible and straight into the pump (Absolute minimum number of elbows or tees in the suction line, like any pump application)
- The compression of the hose by roller or shoe creates a pulsating flow, hence limiting the length and dimension of suction and discharge lines, unless a pulsation dampener is used



COMMUNICATION NEEDS

➤ Input and Output Signals

- DFXa and DFYa are “smart” pumps
 - Control: manual, external contact, and analogue control (4-20 mA)
 - Relay: 4-20 mA analogue output + fault indicating
- DFB, DFC, DFD pumps require VFD for speed adjustment



CERTIFICATION


➤ NSF-61

- DFB series pumps with stainless-steel and PVDF connections with either EPDM, Natural Rubber (NR), or Hypalon
- DFC series 30, 40, and 50 series pumps with stainless-steel and PVDF connections with either EPDM, Natural Rubber (NR), or Hypalon
- DFC series 60 and 70 pumps with stainless-steel connection only with either EPDM, Natural Rubber (NR), or Hypalon

Note: The list of the chemicals can be provided by the ProMinent team.



CERTIFICATION




➤ FDA:

- DFYa, DFB, and DFC with stainless-steel tri-clamp connection, NBR-A hose, and food grade grease
- DFXa with 'F' option for FDA-compliant

PAUSE FOR QUESTIONS


**Any Questions
at this Time?**

Selecting & Quoting



TUBE/HOSE LIFETIME

- Chemical
- Speed
- Temperature
- Discharge Pressure
- Suction Conditions



CHEMICAL COMPATIBILITY CHART

- ProMinent Chemical Resistance Charts to confirm the fluid to be pumped is compatible with the hose and the connections/hose inserts

Chemical resistance chart - Hoses

	HOSES					CONNECTIONS			
	Natural rubber (NR)	Buna-N (NBR)	EPDM	Hypalon (CSM)	Norprene A-60-F	STAINLESS STEEL	POLYPROPYLENE	PVDF	HALAR
Medium									
Acetal	C	C	C	C		A	C	C	C
Acetic Acid 10%	A	C	A	A	A	A	B	A	A
Acetic Acid 20%	B	C	A	A		A	B	A	A
Acetic Acid 30%	B	C	A	A		A	B	A	A
Acetic Acid 99%	C	C	A	B		A	B	A	A
Acetic Acid 50%	B	C	A	A	B	A	B	A	A
Acetic Acid Anhydride	C	C	B	C	A	A	B	A	A


'A' means no chemical attack. Totally compatible

'B' means small chemical attack. Only to use when there aren't better options

'C' means strong attack. The material is not suitable for the application.

HOSE LIFETIME

Estimated Hose Life



Note: always choose **natural rubber (NR)**, if material is compatible with chemical.

PRODUCT CATALOG

■ Link:

<https://www.prominent.us/en/Products/Products/Product-Catalog/Product-Catalog.html>

Capacity Data					
	DFCU30	DFCU40	DFCU50	DFCU60	DFCU70
DFCU Series					
Compression	Roller	Roller	Roller	Roller	Roller
Connection	1 1/4"	1 1/2"	1 1/2"	2"	2 1/2"
Capacity gal/rev	0.11	0.24	0.39	0.82	1.76
Max. Flow GPM	7.4	14.4	23.1	41.2	106.4
Max. Pressure Reinforced Hoses	116 psi	116 psi	116 psi	116 psi	116 psi
Tubing	N/A	Norprene	N/A	N/A	N/A
Max. Pressure Tubing	N/A	30 psi	N/A	N/A	N/A

All models are available with one of the following reinforced hoses: Natural Rubber, Buna, EPDM, Hypalon

DFCU/A Series



[Select Language / Country or Region USA](#)

[INDUSTRY SOLUTIONS](#)
[APPLICATIONS](#)
[PRODUCTS](#)
[SERVICE](#)
[COMPANY](#)
[CONTACT](#)

Product Catalog

Product catalogue – all innovations presented in detail

Newly developed pumps, standardized metering systems, unique UV plants: Our products optimize your process reliability and increase plant efficiency. With ProMinent's product catalogue you have all information at a glance.

You are looking for the matching product or the right system for your specific application in metering technology and water treatment? Just check out in ProMinent's new product catalogue and make your choice.

Complete Water Treatment Solutions

Dosing technology, measurement, control and sensor technology, water treatment and water disinfection as well as digital solutions

[Download >](#)
[Flipbook >](#)

2023 Product Catalog (USA)

Metering pumps, components, metering systems and controllers

[Download >](#)
[Flipbook >](#)

Brochure - Dosing Controlling Disinfecting - Food & Beverage Solutions

[Download >](#)

SELECTION TOOLS – APPLICATION SHEET

- Peristaltic Pump Selection Program to ensure the customer receives the correct peristaltic pump for the application

Application Details

FLUID SPECIFICATIONS

Media:		
Flow rate:	800	l/h
Specific gravity:	1	kg/dm ³
Viscosity:	500	mPas
Vapour pressure (standard: 0,024)	0.024	bar

SUCTION:

Suction diameter:	25	mm
Suction length:	2	m
Suction height:	2	m
External losses:	0	bar

DISCHARGE:

Discharge diameter:	25	mm
Discharge length:	20	m
Discharge height:	10	m
External losses:	0.5	bar

HOSE MATERIAL 1: NR, 2: NBR, 3: EPDM,
4: HYPALON, 5: NBR-A/NR-A, 6: NORPRENE

1


NR

Medium temperature:

25 °C



Press button to select a pump



ProMinent®

HOW TO GET A QUOTE

➤ USA:

- Pump: e-Quote or e-mail to prominentcsd-us@prominent.com
- Custom System: distributors can send RFQ (cc the Regional Sales Manager) by emailing Applications team at engrfq-us@prominent.com


➤ Canada:

- Pump: e-mail to sales-can@prominent.com
- Custom System: distributors can send RFQs to the Sales Rep.

Tips for Designing a System




SYSTEM LAYOUT TIPS




General Installation Tips:

- Suction line should be as short and direct as possible
- The size of the suction and discharge lines need to be at least the same as the pump's connections
- Oversize suction line especially for chemical with high viscosity (150% ID hose)
- Remember to have easy access for maintenance and hose replacement. Use flexible hose or expansion joint (which is removable) at pump outlet
- If system has isolation valves, always install a pressure relief valve
- Install pulsation dampener close to the pump outlet
- Include drain valves

EXAMPLES OF ASSEMBLED SYSTEMS



EXAMPLES OF ASSEMBLED SYSTEMS




DFD pump
Shoe technology

Installation Tips



FLOOR OR WALL MOUNT INSTALLATION



EXTRA INFORMATION

■ YOUTUBE VIDEOS

<https://www.prominent.us/en/Products/Products/Peristaltic-Pumps/p-dulcoflex-dfbu.html>


Hose Replacement:

<https://www.youtube.com/watch?v=7sjq1oq3GW4>

ProMinent®

INDUSTRY SOLUTIONS APPLICATIONS PRODUCTS SERVICE COMPANY CONTACT

Select Language / Country or Region **USA** Enter search term



Peristaltic pumps of the DULCOFLEX DFBu series

Pressures up to 118 psi and flow rates up to 337 gph

The DULCOFLEX RAD pump offers a choice of tubing or reinforced hose in about 1/2 the space needed for conventional hose pumps.

Product description

Overview | **Video** | Application | Technical Data | Downloads

How to change the hose on your DULCOFLEX Pump

How to change the hose on your DULCOFLEX Pump

Motor Selections DFB pumps

- Motors for the DFB pumps are provided from 1/2 hp to 1 hp and can be offered as follows:
- 115/208/230V/1PH/60 - FIXED SPEED
- 230/460V/3PH/60C - VARIABLE SPEED 1000:1
- 230/460V/3PH/60C - VARIABLE SPEED 1000:1 CHEM DUTY / WASHDOWN DUTY
- MOTOR 115/208/230V/1PH/60 - FIXED SPEED (EXPLOSION PROOF)
- 230/460V/3PH/60C - VARIABLE SPEED 1000:1 (EXPLOSION PROOF C1/ GROUPS C&D C3 GROUPS E&F)

DFB Pump Listing

SUMMARY

- Information gathering is necessary to provide the appropriate pump and/or system:
 - Fluid data
 - Site specific specifications
- Ensure selection of proper components and layout when designing a dosing system
- Tools are available to help with selection and quoting
- ProMinent offers support throughout the entire life cycle of the peristaltic pump system



THANK YOU FOR YOUR ATTENTION

Ana Dias
dias.ana@prominent.com

Matt Jackson
jackson.matthew@prominent.com